

# DAIHATSU : Feroza

1 of 1

10/88-98: F300

	PRODUCT	FRONT	REAR	PRODUCT INFORMATION	TYPE
<b>SHOCK ABSORBERS</b>	<b>Toughdog Gas</b> 35mm bore	<b>BD2057T</b> <b>BD2057T</b> \$125 ea	<b>BD1102T</b> <b>BD1104T</b> \$125 ea	35mm bore/twin tube Nitrogen Gas Charged	OE Height <b>40mm lift</b>
	<b>Toughdog Adjustable</b> 40mm bore	<b>USE</b> <b>GAS SHOCK</b>	<b>BM401104</b> \$200 ea	40mm bore/twin tube/60mm casing/ 9stage adjustment	<b>40mm lift</b>
<b>LEAF SPRINGS</b>	<b>Premium Pack</b> Rear: 4 Leaf Spring		<b>T67</b> \$310 ea	Light Load up to 300kg	<b>40mm lift</b>
<b>TORSION BARS</b>	<b>Toughdog</b>	<b>4WTB-197</b> \$535 pair		1.093 / 26mm	All models
<b>Remember to adjust Torsion Bars after fitting Shocks.</b>					
<b>URETHANE PRODUCTS</b>	Shackle bushes		<b>TDUK-003</b> \$105 kit	1 kit required	All models
<b>U BOLTS</b>	U Bolts must be tightened at 500km service		<b>TDUB-027</b> \$40 kit	2 kits required	All models

\* Warranty / Fitment sheets must be filled out when a new suspension is fitted. Failure to do so may affect warranty. \*  
Fitment sheet can be found on page 4 of this catalogue.

# DAIHATSU : Feroza II

1 of 1

4/93-99: F310

	PRODUCT	FRONT	REAR	PRODUCT INFORMATION	TYPE
<b>SHOCK ABSORBERS</b>	Toughdog Gas 35mm bore	<b>BD2057T</b> <b>BD2057T</b> \$125 ea	<b>BD1005T</b> <b>BD1007T</b> \$125 ea	35mm bore/twin tube Nitrogen Gas Charged	40mm lift
	Toughdog Adjustable 40mm bore	USE GAS SHOCK	<b>BM401005</b> <b>BM401007</b> \$200 ea	40mm bore/twin tube/60mm casing/ 9stage adjustment	OE Height 40mm lift
<b>LEAF SPRINGS</b>	Premium Pack Rear: 4 Leaf Spring		<b>T76</b> \$330 ea	Light Load: up to 300kg	40mm lift
<b>TORSION BARS</b>	Toughdog	<b>4WTB-197</b> \$535 pair		1.093m / 26mm	All models
<b>Remember to adjust Torsion Bars after fitting Shocks.</b>					
<b>URETHANE PRODUCTS</b>	Shackle bushes		<b>TDUK-022</b> \$105 kit	1 kit required	All models
<b>U BOLTS</b>	U Bolts must be tightened at 500km service		<b>TDUB-027</b> \$40 kit	2 kits required	All models

\* Freight should be added where required. \*

To determine what load you are carrying remember to include the weight of all passengers & driver in the total weight.